

KTM 790 ADV Windshield Installation Manual

Thank you for purchasing the KTM 790 Windshield from RADE/GARAGE. The installation is quite simple, and may take up to only 1 hour including all preparations.

0/ See your bike before and after the 790 windshield is installed

BEFORE:



AFTER:



1/ Remove the OEM screen and spoilers

a/ Remove the bolt holding the OEM screen and pull the screen out



b/ Behind the spoilers are bolts, one on each side. Remove them. Then carefully lift each spoiler up. They have plastic hooks locked in the plastic tower – don't use force! (RISK OF BRAKING)



2/ Mount the holders

a/ Remove the original plastic cap. There is one bolt on each side, remove them and pull up the cap.



b/ Take the supplied metal plate with the 3 rivet nuts. Then remove the thread inserts from the original cap and put them in the metal plate. When done, place this assembly instead of the plastic cap.



c/ Replace bolt in the main bracket with the supplied M5x16 bolts. Also insert the rubber nuts into both sides of the main bracket.



d/ Use the 3 supplied longer M5 bolts to attach the GPS bracket. It can be situated closer or further from the windshield. We recommend the orientation CLOSER to the windshield.



e/ Take the supplied metal hooks. First put in the rubber nuts and then insert one metal hook on each side in place the of the original OEM spoilers.



3/ Prepare and mount the windscreen

a/ Put on the transparent rim around the edge of the windscreen and secure it with the black staple.



b/ Mount the windscreen with the M5x16 bolts. To avoid the metal holders scratching the windshield place in between the windscreen and the metal holder the supplied rubber washers. It means the rubber washer goes under the windscreen and the white plastic goes under the bolt's head.



Congratulation! The installation is finished and you can start enjoying your upgraded bike ☺



Thanks again.

RADE/GARAGE team